



W.B.C. SUPER / BROOD CHAMBER

ASSEMBLY INSTRUCTIONS

KIT CONSISTS OF: 2 x GROOVED PIECE (A).
2 x PLAIN PIECE (B).
4 x SQUARE ENDED BAR.
2 x THIN STRIP (C).
2 x RUNNER.
1 x PKT. 1" & $\frac{3}{4}$ " NAILS.

ESSENTIAL TOOLS: HAMMER.
RULER.
PENCIL.
PINCHERS.

ADVISABLE TOOLS: 2 x 2' SASH CRAMP

INSTRUCTIONS:

MARK ON THE OUTSIDE OF (A) THE CENTRE OF THE TWO GROOVES (THIS IS TO HELP WHEN NAILING LATER).

TAKE ONE OF THE GROOVED PIECES (A) AND PUT SOME GLUE IN THE GROOVES. PUSH THE TWO PLAIN PIECES (B) INTO THE GROOVE, MAKING SURE THAT THEY ARE LEVEL WITH THE BOTOM OF PIECE (A). FIX ON THE OTHER PIECE (A).

NAIL TOGETHER AND ENSURE THAT THE BOX IS SQUARE (BY MEASURING THE TWO DIAGONALS, WHICH SHOULD BE EQUAL).

GLUE THE SQUARE BARS INTO PLACE, AND NAIL FROM THE INSIDE. THE LOWER BAR SHOULD BE LEVEL WITH THE BOTTOM, AND THE UPPER BAR LEVEL WITH THE TOP OF PIECE (B), AS SHOWN IN THE RIGHT HAND DIAGRAM.

MAKE SURE THAT THE BOX IS STILL SQUARE.

ATTACH THE THIN STRIPS (C) TO EACH SIDE AS SHOWN, SO THAT THE TOP OF THESE STRIPS ARE LEVEL WITH THE TOP OF PIECE (A).

FINALLY ATTACH THE RUNNERS USING $\frac{3}{4}$ " NAILS.

