



W.B.C. HIVE FLOOR

ASSEMBLY INSTRUCTIONS

KIT CONSISTS OF: 4 x LEGS.
2 x SIDE PIECE (A).
1 x BACK PIECE (B).
1 x FRONT STRIP (C).
4 x FLOOR PIECES (D,E,F,G).
(ALL DIFFERENT).
2 x WEDGES.
2 x FLOOR STRIP (H).
1 x FLOOR STRIP (J).
1 x LOCATION STRIP FOR B.CHAMBER (K).
1 x PKT. 1½" & 1" NAILS & SCREWS.

ESSENTIAL TOOLS: HAMMER.
SCREWDRIVER.
RULER.
PENCIL.
PINCHERS.

ADVISABLE TOOLS G - CLAMP.

INSTRUCTIONS:

TAKE ONE SIDE PIECE (A), AND THE BACK PIECE (B) AND NAIL TOGETHER, AS SHOWN IN THE DIAGRAM, (SO THAT THE NAILS ARE PASSING THROUGH (B) INTO (A) AND NOT VICE VERSA).

ATTACH THE OTHER SIDE PIECE TO THE OTHER END OF PIECE (B).

FIX THE FRONT STRIP (C) IN PLACE MAKING SURE THAT THE BASE IS SQUARE (MEASURE THE TWO DIAGONALS, THEY SHOULD BE EQUAL).

SELECT THE FLOOR PANEL (D) (PLAIN ON ONE EDGE & 5½" WIDE), AND POSITION SO THAT IT IS FLUSH WITH THE BACK OF (B), AND IT IS THE CORRECT WAY ROUND (SEE DIAGRAM). NAIL ALONG THIS BACK EDGE ONLY.

NOW POSITION FLOOR PIECE (E) (WHICH IS REBATED ON BOTH ENDS). WHEN THIS PIECE IS IN PLACE, UNDER (D), FINISH NAILING (D) AND THEN NAIL THE TWO REAR NAILS INTO (E) - ONE EACH SIDE.

PLACE PIECE (F), FINISH NAILING PIECE (E), NAIL (F) IN PLACE. PIECES (D), (E) & (F) SHOULD END UP FLUSH WITH THE EDGES OF THE FLOOR.

POSITION AND NAIL (G). THIS PIECE WILL OVER HANG THE FRONT AND SIDES OF THE FLOOR.

POSITION WEDGES SO THAT THE DISTANCE FROM THE BACK OF THE FLOOR TO THE REBATE IS $19 \frac{7}{8}$ ". FIX IN PLACE USING $1\frac{1}{2}$ " NAILS.
FIX PARTS (H) AND (J) ONTO THE FLOOR USING 1" NAILS, AS SHOWN, SO THAT THERE IS AT LEAST $1\frac{1}{16}$ " LEFT FREE AROUND (H & J) FOR THE LIFT.
FIX PIECE (K) IN PLACE AS SHOWN IN THE DIAGRAM.

ATTACH THE LEGS USING THE SCREWS PROVIDED. NOTE THAT TWO OF THE LEGS ARE ANGLED LEFT AND RIGHT, AND THESE FIT AT THE FRONT OF THE FLOOR.
DO NOT GLUE THE LEGS, SO THAT THEY CAN BE REPLACED WITH A FRESH SET IF NECESSARY.

